



4 kanals logger for load celler med mV/ V-signal/ *4-channel logger for load cells with mV/V-output.*



*4 veieceller tilkoblet PC-logger/ 4 load cells connected to PC-logger.*

- Kan logge inntil 4 loadceller med mV/V-signal samtidig/ *logs up to 4 load cells with mV/V-output simultaneously.*
- Loggedata kan eksporteres for videre behandling i Excel/ *log data can be exported and handled in Excel.*
- Loggeintervall: 5 Hz (200ms)/ *logging interval: 5 Hz (200ms)*
- Programvare med avlesing for hver tilkoblet load celle/ *software displays each load cell connected*